


## IBS-TH1 电池更换操作图示




- 1、Using a slot type screwdriver or fingernail to insert it and pry up the bottom cover.



- 2、Using a slot type screwdriver to loosen the four screws which are indicated in picture, then take out the PCB board.



3. Push out the battery in the direction of picture indicates and change a new one. Please pay attention do not touch other parts of PCB board in case for electrical short circuit.



4. Closing the cover as shown in the picture. The unit will enter working mode after 60 seconds after finish the battery changes.